



491 W. Garfield Ave., Coldwater, MI 49036
Phone: 517-279-2135
Web/live chat: www.bds-suspension.com
E-mail: tech@bds-suspension.com

Part#: **012208**

Product: **2" Rear Block Kit**

Application: **03-05 3/4 Ton Dodge 4WD**

READ AND UNDERSTAND ALL INSTRUCTIONS AND WARNINGS PRIOR TO INSTALLATION OF SYSTEM AND OPERATION OF VEHICLE.

PARTS LIST

Part #	Qty	Description
2KB-W34	2	2" Block Painted - 3/4" Pin
963121212R	4	9/16 x 3-1/2 x 12-1/2" Round U-Bolt
N96FH	8	9/16" Fine High Nut
W96S	8	9/16" SAE Flatwasher
01599	2	Center Pin

INSTALLATION INSTRUCTIONS

1. Park the vehicle on a clean, flat surface and block the front wheels for safety.
2. Raise the rear of the vehicle and support with jack stands under the frame rails ahead of the rear spring hangers.
3. Support the rear axle with a hydraulic jack and remove the OE shocks. Retain hardware.
4. Remove the passenger's side u-bolts. Lower the axle from the spring. Remove the middle plastic center pin from the leaf pack and install the new press-in steel center pin provided.
5. Place the new block on the spring perch so that the short end of the block is to the front of the vehicle. Align the pin in the axle perch hole.
6. Raise the axle to the spring while aligning the center spring pin to the hole in the block.
7. Install the new u-bolts and snug the assembly together. Final u-bolt torque should be done with the weight of the vehicle on the springs.
8. Repeat the procedure on the driver's side.
9. Install the new BDS shocks with the OE hardware.
10. Lower the vehicle to the ground.
11. Torque the u-bolts to 100-120 ft-lbs.
12. Check all hardware for proper torque.
13. Check hardware after 500 miles.

NOTICE TO DEALER/INSTALLER

These instructions, the warning card, and included decals must be given to the owner of this BDS Suspension product.

For questions, technical support and warranty issues relating to this BDS Suspension product, please contact your distributor/installer before contacting BDS Suspension directly.

Sold/Installed by: