



491 W. Garfield Ave., Coldwater, MI 49036
Phone: 517-279-2135
Web/live chat: www.bds-suspension.com
E-mail: tech@bds-suspension.com

Part#: **121507**

Product: **Sway Bar End Links**

READ AND UNDERSTAND ALL INSTRUCTIONS AND WARNINGS PRIOR TO INSTALLATION OF SYSTEM AND OPERATION OF VEHICLE.

SAFETY WARNING BDS Suspension Co. recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

INSTALLATION INSTRUCTIONS

1. Park the vehicle on a clean flat surface and block the rear wheels for safety.
2. Remove the factory rear sway bar link completely from the vehicle and save the OE fasteners.
3. Apply grease to the supplied bushings and install them in to the supplied end links. Grease the supplied sleeve and install them in to the supplied bushings.
4. The upper mount of the OE link is rather narrow and you will need to compress the supplied link bushing in order to install the link. To ease installation, touch the supplied bushing edge against a grinder to create a taper on the starting edge of the bushing. This will allow you to start the bushing in the upper pocket.
5. Use the OE fasteners to attach the end links to the upper mounts and the sway bar. Torque to factory specification.

PARTS LIST

Part #	Qty	Description
911103	2	Sway Bar End Link
SB58RB	4	Hourglass Bushings
14	4	Sleeve